


# Inspextor UI Structure Overview


To best read this guide this section establishes the structure of an Inspextor webpage as well as introduce the vocabulary associating the supported Inspextor PoE Devices to their representation in the Inspextor Software.

## Inspextor Webpage Structure

The Inspextor software was designed with user experience in mind. It utilizes a prominent vertical navigation system to allow users to quickly navigate through the system. It also utilizes a modularized system of panels on each page to clearly define the structures of data and its use case. The subsection below will introduce those features. In future sections we will refer to these by there designators labeled below



# Page Header



The Page header as pictured above is present on each page as the user navigates through the software providing the user with important access to service impacting information in the Hot Buttons section while providing a means of translation into different languages.

≡ inspeXtor

The 3 Bars Adjacent to the InspeXtor Logo are referred to as a hamburger menu and allow the user to access the Vertical Navigation bar

Select Language ▾  
Powered by Google Translate

The InspeXtor Software utilizes the Google Translate to provide an update selection of 133 different languages for the user to select from.



The Hot Buttons that are found in the Header Bar are utilized by the user to understand the state of the system and direct information each icon is described in greater detail below



The **Status Light** allows the user the ability to see the status of the system and On-Hover a detail will appear describing the system state.



The **Mobile Dashboard** provides a quick means to change the system visibility to suit vertical orientated devices (Details can be found in the [UI Mobile Dashboard Section](#)).



The **Help** section is available on each page and provides direct information to allow the user direct access to page specific data for the InspeXtor Software.



The **Alerts** are a quick view of the defined alerts page where system and user define alerts can be viewed in real time



The **User Control** allows a quick navigation to the User's profile as well as provide the means of logging out


## Page Footer



The Page footer as pictured above is present on each page the data present while marginally less important provides much needed support content when reaching out to the MHT Support Team with question. The Contract ID is what the team utilizes to tie your installation to the license and the version is the Version Instance installed on your MHT Inspextor Appliance.

## Vertical Navigation Pane

The Vertical navigation pane provides the main structure of the Inspextor software. Web pages are sorted into each Navigation Tab based on User-Centric perceived setting. In the displayed example the Remote Control Tab is located under the Controls tab providing a means of grouping these pages and functions for future development.



***Navigation Tabs not shown here please see supplemental documentation for specific modules***