

Task Light and Desk Circuits

- MHTi-NODE-90-CV provides power to MHTi-SMD-INT-L and the CV Tasklight
- For Plug and Play compatibility utilize the MHTi-RJF-2WIRE adapter to connect The Tasklight to Channel 2

